

BMW Motorrad Maintenance schedule K 1200 RS as of model year 2001, Integral ABS



Customer	Licence No.	Mileage	BMW Inspection at 1000 km/600 miles	BMW Maintenance Service every 10000 km/6,000 miles	BMW Inspection every 20000 km/ 12,000 miles	BMW Annual Service
Job Order No.	Date	Mechanic's signature				
Read out the fault memory with the BMW MoDiTeC unit			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
[Integral ABS] perform bleed test with BMW MoDiTeC			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Check throttle cable play, adjust if necessary			<input type="checkbox"/>		<input type="checkbox"/>	
Change engine oil while at operating temperature If the motorcycle is ridden only for short distances or at outside temperatures below 0°C (32 °F), this work must be done every 3 months or at least every 3,000 km (1,800 miles) *)			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Change oil in gearbox while at operating temperature at least every 2 years *)					<input type="checkbox"/>	<input checked="" type="checkbox"/>
Change oil in rear wheel drive while at operating temperature, Every 40,000 km (24,000 miles), Every 2 years at the latest *)			<input type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
Examine brake pads and discs for wear, replace if necessary *)				<input type="checkbox"/>	<input type="checkbox"/>	
Check operation of brake system and freedom from leaks; repair/replace items if necessary *)					<input type="checkbox"/>	
[Integral ABS] Checking brake fluid level at handgrip				<input type="checkbox"/>	<input type="checkbox"/>	
[Integral ABS] change brake fluid in wheel circuit at least every 12 months						<input checked="" type="checkbox"/>
[Integral ABS] change brake fluid in control circuit at least every 2 years *)						<input checked="" type="checkbox"/>
[Integral ABS] perform bleed test with BMW MoDiTeC						<input type="checkbox"/>
[OE, without Integral ABS] Check the front/rear brake fluid level				<input type="checkbox"/>	<input type="checkbox"/>	
[OE, without Integral ABS] Change the brake fluid at least once a year						<input checked="" type="checkbox"/>
Check clutch operating fluid level				<input type="checkbox"/>	<input type="checkbox"/>	
Change clutch fluid every 2 years at the latest *)						<input checked="" type="checkbox"/>
Replace fuel filter *) generally every 40,000 km (24,000 miles), if the fuel is of poor quality, every 20,000 km (12,000 miles)					<input checked="" type="checkbox"/>	
Check coolant level and concentration, top up if necessary and check cooling system for leaks			<input type="checkbox"/>		<input type="checkbox"/>	
Replace the coolant at least every 2 years *)						<input checked="" type="checkbox"/>
Check battery acid level, if necessary add distilled water Clean/grease battery terminals if necessary					<input type="checkbox"/>	<input type="checkbox"/>
Replace intake air cleaner element If severe dirt and dust are encountered, replace the intake air cleaner every 10,000 km (6,000 miles) or even more frequently *)					<input checked="" type="checkbox"/>	
Check function of side stand contact switch			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Grease side stand bearing, check that the centre stand moves freely, and grease it if necessary *)				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Check the steering damper				<input type="checkbox"/>	<input type="checkbox"/>	
Check tightness of rear wheel studs			<input type="checkbox"/>			
Check rear wheel bearing play by rocking wheel					<input type="checkbox"/>	
Check swinging arm bearings (free of play), adjust if necessary *)			<input type="checkbox"/>		<input type="checkbox"/>	
Check valve clearances, adjust if necessary *)					<input type="checkbox"/>	
Replace the lining of the chain tensioning rail, chain guide rail and thrust piece every 60,000 km (36,000 miles) *)					<input checked="" type="checkbox"/>	
Replace spark plugs					<input type="checkbox"/>	
Final inspection with road safety and functional check: - Condition of tires and wheels, tyre pressure - Clutch, gearshift mechanism, hand and foot brake, Integral ABS, steering system - Lights and signalling equipment, telltale and warning lights, instruments, horn - Optional equipment and accessories fitted - Trial run if necessary			<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

*) Write up on separate invoice; Not part of standard service procedure