BMW Motorrad
Maintenance schedule
F 650 CS

Customer	Licence No.	Odometer reading
Job Order No.	Date	Mechanic's signature

	BMW Inspection at 1 000 km/ 600 miles	BMW Service every 10 000 km	BMW Inspection every 20 000 km	BMW Annual Service
Use BMW diagnosis system to read stored error codes from fault memory	☐	☐	☐	☐
Change the engine oil **[engine only]** while at regular operating temperature and replace the oil filter element	☐			
Change the engine oil **[engine and oil tank]** while at regular operating temperature and replace the oil filter element **If the motorcycle is ridden only for short distances or at outside temperatures below 0 °C (32 °F), this task must be performed at least every 3,000 km (1,800 miles).**		☐	☐	☐
Clean oil strainer in frame **once only at 10,000 km/6,000 miles)**		☐		
Check coolant level and correct if necessary	☐	☐	☐	
Grease rubber grommets for cover insert	☐	☐	☐	☐
Change the coolant*) **every two years**				■
Replace spark plug			☐	
Check valve clearance and adjust as necessary *)		☐	☐	
Empty the drain hose from the air filter housing	☐	☐	☐	
Replace intake air filter element **If riding conditions are very dirty or dusty, clean or replace the air intake filter every 10,000 km (6,000 miles), check every 3,000 km (1,500 miles)**		■	☐	
Replace fuel filter*) **Every 40,000 km (24,000 miles)**			■	
Check clutch play, adjust if necessary	☐	☐	☐	
Check brake pads and discs for wear, replace as necessary*)		☐	☐	
Check brake fluid level at front and rear		☐	☐	
Check operation of brake system and check for leaks; repair/replace items if necessary *)			☐	
Change the brake fluid once a year **at least**				☐
[ABS] Replace primary sealing boot in front and rear Brake master cylinders *) **Every 40,000 km (24,000 miles)**			■	
Replace toothed belt *) **Every 40,000 km (24,000 miles)**			■	
Check toothed belt and replace if necessary *)		☐	☐	
Check toothed belt wheel and sprocket, replace if necessary *)			☐	
Check belt tension, adjust if necessary *)		☐	☐	
Check battery acid level, add distilled water if necessary		☐	☐	☐
Battery terminals, clean and grease as necessary				☐
Check steering head bearings, adjust*), or replace if necessary *)		☐	☐	
Grease side stand		☐	☐	
Using torque wrench, check that bolts and nuts of engine mountings, threaded fasteners of exhaust elbow, threaded fasteners of frame, rear-frame threaded fasteners, and eccentric clamp are tightened to specified torque	☐	☐	☐	☐
Final inspection with road safety and functional check: – Clutch, gear shift – Steering – Handbrake and foot brake – Side-stand switch – Condition of tyres and wheels, tyre pressures – Lights and signalling equipment, telltale and warning lights, instruments – Optional equipment – Road test	☐	☐	☐	☐

***) Invoiced as separate items; ■ not part of standard service procedure**

UX-VS-2, 06.2002

BMW recommends Castrol